



V, VQ系列双联叶片泵

V, VQ Series Double Vane Pumps

选购指南 HOW TO ORDER

****VQ	**	A	**	(F)	_*	*	20	*
系列 Series	轴端泵排量 Displacement Shaft End	连接型式 Connection Type	盖端泵排量 Displacement Cover End	安装形式 Mounting Type	轴伸形式 Shaft Type	油口位置 Port Position	设计号 Designing No.	旋转方向 Rotation
2520VQ(V)	10,12,14,15,17,19,21	A-菱形法兰 A-SAE 4-螺栓法兰 4-Bolted Flange	2,3,4,5,6,7,8,9,10,11,12,14	无标记:法兰型 OMIT:Flange	1-带键直轴 1-straight shaft with key 86-重型带键直轴 86-heavy-duty straight shaft with key 11-花键轴 11-spline shaft	参照18页 Refer to page 18	20	(从泵的轴端看) (Viewed from Shaft End) R:顺时针旋转 Clockwise L:逆时针旋转 L-Anticlockwise
3520VQ(V)	21,25,30,32,35,38,45		2,3,4,5,6,7,8,9,10,11,12,14					
3525VQ(V)	21,25,30,32,35,38,45		10,12,14,15,17,19,21	F-脚座型 F-Foot				
4520VQ(V)	42,45,50,57,60,66,75		2,3,4,5,6,7,8,9,10,11,12,14					
4525VQ(V)	42,45,50,57,60,66,75		10,12,14,15,17,19,21					
4535VQ(V)	42,45,50,57,60,66,75		21,25,30,32,35,38,45					

V, VQ系列泵芯

V, VQ Series Cartridge Kits

选购指南 HOW TO ORDER

C-	25V(Q)	-5	-R
系列 Series	排量 Displacement	旋转方向 Rotation	
C-单泵泵芯 Single pump cartridge kits	20V(Q)	2,3,4,5,6,7,8,9,10,11,12,14	从轴端看 Viewed From Shaft End R-顺时针 Clockwise L-逆时针 Anticlockwise
双联泵轴端泵芯 Double pump shaft end pump cartridge kits	25V(Q)	10,12,14,17,19,21	
CT-双联泵盖端泵芯 Double pump cover end pump cartridge kits	35V(Q)	21,25,30,35,38	
	45V(Q)	42,45,50,57,60,66,75	